



14. At the end of the shift or fire watch and/or after 30 minutes after the end of the hot work, the fire watch or general contractor safety officer shall record his findings and ensure no danger is present.
15. Once complete, the fire watch and/or the general contractor safety officer shall sign off on the daily report and call the University Emergency Communications Center at 474-7721 to deactivate the permit.
16. Once all work authorized for the permit is complete, the permit shall be deactivated and not re-used on subsequent scopes of work or projects.